仕様変更のお知らせ

SonicCell の本体システムが Version 1.11 に変更になりました。これに伴い、取扱説明書の内容を以下のように 変更させていただきます。

変更点

- Mac OS X 10.5 に対応しました。(Roland SonicCell Driver Ver. 1.01 をお使いください。)
- SonicCell の [SMF/オーディオ・ファイル・プレーヤー] 機能で、Playlist Editor で管理できる曲数が 99 曲から 399 曲 に増えました。Playlist Editor Ver.1.10 をご使用いただくことで、399 曲扱えるようになります。
- MIDI メッセージで、SMF / オーディオ・ファイル・プレーヤーのスタート/ストップが行えるようになりました。 システム設定の「Sync Mode」に REMOTE が追加され、REMOTE に設定することで、MIDI メッセージ FA: Start、FB: Continue、FC: Stop を受信することが可能になります。

P.32『動作条件』

(変更前)		(変更後)	
Mac OS		Mac OS	
OS:	Mac OS 10.4.3 以降	OS:	Mac OS 10.4.3 以降
CPU/クロック:	PowerPC G4 1GHz以上/Intelプロセッサ		44.1/48kHz でお使いの場合: Intel プロセッサ/ PowerPC G4/G5 1GHz 以
RAM:	512 MB以上		上
ハードディスク 空き容量:	160MB以上		96kHz でお使いの場合: Intel プロセッサ/ PowerPC G5
画面解像度/ 色数:	1280 × 800 ドット以上/ 1670 万色以上 USB 2.0 ポートを標準で搭載している Apple		※ Mac OS X 10.5 以上でお使いの場合、Intel プロセッサ または PowerPC G5 以上。
その他:	Macintosh シリーズ CD-ROM ドライブ		※ パフォーマンスを必要とするアプリケーションでお使いになる場合、そのアプリケーションが、お使いの Macintosh に搭載されている CPU に対応している必要があります。
		RAM:	512 MB以上
			※ Mac OS X 10.5 以上でお使いの場合、1GB 以上。
		ハードディスク 空き容量:	160 MB以上
		画面解像度/ 色数:	1280 × 800 ドット以上/ 1670 万色以上
		その他::	USB 2.0 ポートを標準で搭載している Apple Macintosh シリーズ
			CD-ROM ドライブ

P.164『ソングの再生』

(変更前)

SonicCell で扱うことのできるソングやプレイリストは、最大で 99 個

(ルート・ディレクトリ上で 99 個、SonicCell フォルダ内で 99 個。 プレイリスト・エディター上で扱えるプレイリストも 99 個です。)

(変更後)

SonicCell で扱うことのできるソング数は、ルート・ディレクトリで 99曲、プレイリスト・エディターで399曲です。

(プレイリスト・エディターは SonicCell フォルダにソング・データを 置きますので、直接データを追加、削除、変更するとプレイリストが表 示できなくなることがあります。)

P.246 「MIDI インプリメンテーション

(変更前)

- システム・リアルタイム・メッセージ
- タイミング・クロック

ステータス

F8H

- ※ Sync Mode パラメーター (System) が SLAVE の時に受信します。
- アクティブ・センシング

ステータス

FEH

※ アクティブ・センシングを受信すると、それ以降のすべてのメッ セージ間隔を監視する状態になります。監視している状態では、 メッセージ間隔が 420ms を超えると、オール・サウンド・オフ/ オール・ノート・オフ/リセット・オール・コントローラーを受信 したときと同じ処理をして、メッセージ間隔を監視しない状態に戻 ります。

(変更後)

- システム・リアルタイム・メッセージ
- タイミング・クロック

ステータス

F8H

- ※ Sync Mode パラメーター (System) が SLAVE の時に受信します。
- スタート

ステータス

FAH

- ※ Sync Mode パラメーター (System) が SLAVE または REMOTE の時に受信します。
- コンティニュー

ステータス

FBH

- ※ Sync Mode パラメーター (System) が SLAVE または REMOTE の時に受信します。
- ストップ

ステータス

FCH

- ※ Sync Mode パラメーター (System) が SLAVE または REMOTE の時に受信します。
- アクティブ・センシング

ステータス

FFH

※ アクティブ・センシングを受信すると、それ以降のすべてのメッ セージ間隔を監視する状態になります。監視している状態では、 メッセージ間隔が 420ms を超えると、オール・サウンド・オフ/ オール・ノート・オフ/リセット・オール・コントローラーを受信 したときと同じ処理をして、メッセージ間隔を監視しない状態に戻

P.273 「MIDI インプリメンテーション・チャート

(変更前)

リアルタイム : クロック 送信× 受信〇 : コマンド 送信× 受信×

(変更後)

リアルタイム : クロック 送信× 受信〇 :コマンド 送信× 受信〇

© 2008 ローランド株式会社

本書の一部、もしくは全部を無断で複写・転載することを禁じます。



SonicCell 40784967

Notice of changes in specifications

The internal system of SonicCell has been updated to version 1.11. In conjunction with this change, please make the following changes to the owner's manual.

Changes

- SonicCell is compatible with Mac OS X 10.5. (Please use Roland SonicCell Driver Ver. 1.0.1.)
- In SonicCell's "SMF/Audio File Player" function, the number of songs that can be managed by the Playlist Editor has increased from 99 songs to 399 songs. By using Playlist Editor Ver. 1.10 you can handle up to 399 songs.
- MIDI messages can now be used to start/stop the SMF/Audio File Player.
 REMOTE has been added as an option for "Sync Mode" in the System settings. When REMOTE is selected, it will be possible to receive the MIDI messages FA: Start, FB: Continue, and FC: Stop.

Page 32 "SonicCell System Requirements"

(Before change)

Mac OS

Operating System: Mac OS 10.4.3 or later

CPU/Clock: PowerPC G4 1 GHz or higher/

Intel processor

RAM: 512 MB or more

Hard Disk: 160 MB or more

Display/Colors: 1280 x 800 or higher/

1670 million colors or more

Others: Apple Macintosh series computer with

on-board USB 2.0 CD-ROM Drive

(After change)

Mac OS

Operating System: Mac OS 10.4.3 or later

CPU/Clock: For 44.1/48 kHz operation:

Intel processor, PowerPC G4/G5 1 GHz

or higher

For 96 kHz operation: Intel processor, PowerPC G5

* For Mac OS X 10.5 or later, an Intel processor or a PowerPC G5 processor

is required.

 If you are using SonicCell with an application that requires a certain level of performance, that application must support the CPU that is installed

in your Macintosh.

RAM: 512 MB or more

* For Mac OS X 10.5 or later, 1 GB or

more.

Hard Disk: 160 MB or more

Display/Colors: 1280 x 800 or higher/

1670 million colors or more

Others: Apple Macintosh series computer with

on-board USB 2.0

CD-ROM Drive

Page 168 "Song playback"

(Before change)

The SonicCell can handle up to a maximum of 99 songs and playlists. (99 items in the root directory, and 99 items inside the SonicCell folder. The Playlist Editor can also handle up to 99 playlists.)

(After change)

The number of songs that can be handled by SonicCell is 99 songs in the root directory and 399 songs in the Playlist Editor.

(The Playlist Editor places the song data in the SonicCell folder, so if you add, delete, or modify the data directly, it may become impossible to display the playlist.)

Page 246 "MIDI Implementation"

(Before change)

■System Realtime Message

Timing Clock

<u>Status</u>

F8H

 This is received when Sync Mode parameter (System) is SLAVE.

Active Sensing

Status

FEH

* When Active Sensing is received, the unit will begin monitoring the intervals of all further messages. While monitoring, if the interval between messages exceeds 420 ms, the same processing will be carried out as when All Sounds Off, All Notes Off and Reset All Controllers are received, and message interval monitoring will be halted.

(After change)

■System Realtime Message

Timing Clock

<u>Status</u>

F8H

 * This is received when Sync Mode parameter (System) is SLAVE.

Start

Status

FAH

 This is received when Sync Mode parameter (System) is SLAVE or REMOTE.

●Continue

Status

FBH

* This is received when Sync Mode parameter (System) is SLAVE or REMOTE.

●Stop

<u>Status</u>

FCH

* This is received when Sync Mode parameter (System) is SLAVE or REMOTE.

Active Sensing

<u>Status</u>

FEH

* When Active Sensing is received, the unit will begin monitoring the intervals of all further messages. While monitoring, if the interval between messages exceeds 420 ms, the same processing will be carried out as when All Sounds Off, All Notes Off and Reset All Controllers are received, and message interval monitoring will be halted.

Page 273 "MIDI Implementation Chart"

(Before change)

System Realtime

: Clock Transmitted X Recognized O
: Command Transmitted X Recognized X

(After change)

System Realtime

: Clock Transmitted X Recognized O
: Command Transmitted X Recognized O

Copyright © 2008 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.



SonicCell 40784967